

# Desktop (-DT1) Assembly Instructions



1. You attach the desktop to the two side units. The desktop will attach to the sides of the units where there is no trim moulding.



2. The next step requires two people. Position the desktop next to the side units. Align the desktop to the side unit. While one person is keeping the top and side unit aligned...



3. The second person will attach the desktop to the side unit using three 1 1/4" course thread wood screws which you screw through the pre-drilled holes in the cleat into the side unit.



4. Repeat step 3 to the remaining side unit.



5. The completed desktop and side units are now ready for use.