

Leg (-LG): with Mounting Strip: Assembly Instructions



1. There are two styles of legs; one with a mounting strip (left) and one with no mounting strip (right).



2. Work with the top turned over on a smooth surface to protect the top surface.



3. Position the leg into the side and front of the desk top trim moulding with the plastic button feet at the top of the leg.



4. Make sure the leg fits tightly against the side and the front. There should be no gaps.



5. Using three 1 1/4" course thread wood screws attach the leg to the top by screwing through the mounting strip into the top. Be careful not to countersink the screws too far.



6. Flip the completed top/leg assembly over, and position it onto the base unit. Note: If there is a second leg and not a base unit, repeat steps 2-5.



7. You mount the top to the base units by screwing directly through the wooden mounting strips from below.



8. Using four 1 1/4" course thread wood screws, attach the base unit to the top by screwing up through the mounting strip into the top. Be careful not to countersink the screws too far.



9. Next the support strip gets installed to the base unit and leg.



10. Approximately 12" from floor, attach the support strip to the back edge of the base unit using two 1 1/4" course thread wood screws.



11. Attach the other side of the support strip to the leg using two 1 1/4" course thread wood screws.



12. The completed leg/support strip assembly.