

Privacy Panel (-PP) Assembly Instructions



1. Line up the privacy panel with the back edge of the base unit.



2. Make sure that the top of the privacy panel and the base unit are flush. The privacy panel can be set back as far back or forward as you wish.



3. Using three 1 1/4" course thread wood screws, attach the privacy panel to the base unit. Then attach the other end of the privacy panel to the remaining base unit.



4. Completed unit with privacy panel installed. Now the top can be installed.